



ACCESSORY



MODEL	PM 5167 SHW-B/DYM 1520QN
	EXPLODED VIEW

PM 5167 SHW-B-DYM1520QN Spare parts list

Pos.	part no.	part description	qty
1	A26800606201	blade tighten bolt	1
2	2105300001C	dish washer	1
3	2105200245A	pressing plate of blade support	1
4	2105200262A	blade	1
5	2105200251A	stamping blade support	1
6	2105400024A	blade support bush	1
7	A26809001201	woodruff key	1
8	21051000163206A	blade support sheath	1
9	A26800300502	locking nut	1
10	2102300109B	driving belt wheel	1
11	2102600016N	triangle belt	1
12	A26800103701	self-driving screw	2
13	21041002600001N	belt protecting cover	1
14	21011001740103N	8"wheel cover	2
15	A26800502801	hex flange locking nut	11
16	2101300065A	bearing	8
17	21011002600001A	wheel assy	2
18	21011001460001A	dust-proof wheel cover	2
19	A26800706202	wavy washer	4
20	A26800201901	tooth screw	4
21	2101200011B	wheel axle fixed board	2
22	2101500068C	front wheel axis assy	1
23	21011000290001A	front wheel axle fixed ring	2
24	2109800049B	spring of front wheel	2
25	A26800500501	hex flange locking nut	3
26	21011003730001F	11" dust-proof wheel cover	2
27	A26800100501	self-driving screw	20
28	2101100081B	wheel gear ring	2
29	21011002610001A	wheel assy	2
30	21011001750103N	11"wheel cover	2
31	2106200153D	connecting rod	1
32	2109100013N	o-rings	1
33	21031000230176D	wash port	1
34	21032002480001A	deck	1
35	A26800502401	locking nut	6
36	21061001694017B	gear board	1
37	A26800202001A	tooth screw	2
38	A26800611201	bolt	4
39	2101200017B	shaft clip	2
40	2106200554C	side-discharge fixing board	1

PM 5167 SHW-B-DYM1520QN Spare parts list

Pos.	part no.	part description	qty
41	2106200053N	side-discharge locating shaft	1
42	A26800800402	spring washer	2
43	A26800201501	tooth screw	2
44	2109800066D	side cover board spring	1
45	21061000900001N	side-discharge cover board	1
46	21041001113209B	side-discharge protecting cover	1
47	A26800900201	open block ring	4
48	2104400013E	left output gear assy	1
49	A26800705102	flat washer	2
50	A26800402302	bearing	2
51	2102400156D	bearing sheath	2
52	A26809000102	column pin	2
53	2102300071A	variable gear box assy	1
54	2104400014E	right output gear assy	1
55	2102200040A	position board	1
56	A26800203001A	cross pan self-driving screw	1
57	2101500121A	rear wheel assy	1
58	A26800900301	open block ring	2
59	2109200020A	adjusting washer	1
60	2106200427D	handle assy	1
61	21021000010001A	handle sheath	1
62	A26800606401	hexagon flange bolt	4
63	21062004490001B	right handle bracket	1
64	2106800006B	right knob spring	1
65	2101300006A	long rod	1
66	2106800007A	left knob spring	1
67	21062004480001B	left handle bracket	1
68	A26800304401	special bolt	2
69	A26800602501	hexagonal bolt	1
70	2103300005B	square washer	3
71	H23050113801	engine	1
72	A26800501502	cap nut	4
73	A26800800202	spring washer	4
74	A26800700701	flat washer	6
75	A26800601903	cup head square neck bolt	4
76	2104100134C	rear cover transparent window	1
77	A26800107101	self-driving screw	2
78	2100X00589	rear deflector	1
79	21062000920001A	lower handle pole	1
80	21061000013201A	wire clamp	1

PM 5167 SHW-B-DYM1520QN Spare parts list

Pos.	part no.	part description	qty
81	A26809004801A	column pin	2
82	21061000273201A	locking handle	2
83	2106200001A	press plate	2
84	2106300008A	locking handle bolt	2
85	2106600013A	cord protecting cover	1
86	A26800500801	locking nut	4
87	A26800501603A	cap nut	2
88	A26800800303	spring washer	1
89	A26800700801	flat washer	2
90	2106300002A	rope guide	1
91	A26800607701	bolt	1
92	2106800009B	flameout cord assy	1
93	2106800428A	driving cord assy	1
94	21061000043201A	cord fixing board	1
95	2106800412A	throttle handle assy	1
96	A26800603601	bolt	1
97	21062002740001C	upper handle	1
98	2106600019A	protecting sheath of handle	1
99	21062002750001A	driving pole	1
100	21062003680104A	flameout pole	1
101	21071000330001A	handle of grass catcher	1
102	A26800104601A	self-driving screw	2
103	21071000310001A	grass catcher	1
104	A26800103202	self-driving screw	2
105	2107200037B	grass catcher bracket	1
106	21077000462133A	grass bag	1
107	21061000910001A	mulching wedge	1
108	21041001150001A	wedge locking button	1
109	2109800022C	spring	1
110	21041001160001A	locking press board	1
111	2109200029B	flat plate	2
112	2012100012A	wrench	1
113	2012100004A	wrench pole	1
114	21031002334079A	head cover	1
115	A26800105402	self-driving screw	2
116	2103200233A	locking block B	1
117	2103800011A	torsional spring	1
118	2103300040A	stationary shaft	1
119	3043301003	split washer	1